



**Car Stereo Compact Disc CD/CD-R/CD-RW/
MP3 Player with PLL FM Stereo Radio
Radio Data System with PTY
USB Port and SD/MMC Card Input
Detachable Front Panel System**

CD-652USMP/FM

Instruction manual

Bedienungsanleitung

Manuel d'instructions



Manuale d'istruzioni

Manual de instrucciones

Manual de Instruções



CD-652USMP/FM



WARNINGS



The exclamation point within the triangle is a warning sign alerting the user of important instructions accompanying the product.



The lightning flash with arrowhead symbol within the triangle is a warning sign alerting the user of “dangerous voltage” inside the unit.



To reduce the risk of electric shock, do not remove the cover. No user serviceable parts inside the unit. Refer all servicing to qualified personnel.



Invisible laser radiation when the unit is opened or interlocks defeated. Avoid exposure to laser beam. Use of controls, adjustments or procedures other than those specified herein may result in hazardous radiation exposure.



This unit must not be exposed to moisture or rain.



This unit should be positioned so that it is properly ventilated.



Do not expose this unit to direct sunlight or heat radiating sources.

CD-652USMP/FM

**Car Stereo Compact Disc CD/CD-R/CD-RW/MP3 Player with PLL FM Stereo Radio
Radio Data System with PTY
USB Port and SD/MMC Card Input
Detachable Front Panel System**






INSTRUCTION MANUAL

Please read this instruction manual carefully and familiarize yourself with your new Radio CD before using it for the first time. Please retain this manual for future reference.

TABLE OF CONTENTS

- Location of Controls
- Features
- Installation
- Precautions and Maintenance
- Operating Instructions
- Specifications

LOCATIONS OF CONTROLS

1. POWER ON/OFF ()
2. FUNCTION SELECT BUTTON: BASS/TREBLE/BALANCE/FADER / TA SEEK/MASK DPI/
RETUNE/AUDIO DSP/LOUDNESS/ESP/CD MULTI/BEEP/SEEK/STEREO/LOCAL (SEL)
3. VOL UP/VOL DOWN FOR BASS/TREBLE/BALANCE/FADER
4. PRESET STATIONS (1,2,3,4,5,6)
5. 'AF' function (ALTERNATIVE FREQUENCIES)
6. 'TA' function (TRAFFIC ANNOUNCEMENT)
7. 'PTY' function (PROGRAM TYPE)
8. DISPLAY BUTTON (DISP)
9. MODE BUTTON (MODE)
10. BAND BUTTON (BAND)
11. AUTOMATIC OR MANUAL TUNING (FREQ UP  OR FREQ DOWN  /
CD TRACK/SEARCH BUTTON
12. AUTO SEEK SEARCH TUNING (A/PS)
13. 'SCAN' AUTOMATIC TUNING CONTROL (SCN)
14. LCD DISPLAY
15. PANEL RELEASE BUTTON ()
16. CD SLOT
17. CD EJECT BUTTON ()
18. PAUSE BUTTON
19. INTRO BUTTON (Preview all Tracks)
20. REPEAT BUTTON 'RPT'
21. RANDOM BUTTON 'RDM'
- 22, 23. + 10 TRACK SEARCH UP/DOWN
24. RESET BUTTON
25. USB PORT
26. MULTI-MEDIA CARD (MMC) / SD CARD SLOT


Detaching and attaching the front panel

The front panel of this unit can be detached in order to prevent the unit from being stolen.

DETACHING THE FRONT PANEL

Before detaching the front panel, be sure to press the PWR button OFF first.

Pull out the panel towards you in order to detach completely the panel from the main unit. Refer to instruction.




ATTACHING THE FRONT PANEL

Make sure the front panel is the right way up when attaching it to the unit as it cannot be attached upside down. Bring side B of panel to side A of main unit.

Insert the panel in and push until it clicks.

Panel is attached.



Notes:

- Do not press the front panel hard against the unit when attaching it. It can be easily attached by pressing it lightly against the unit.
- When you carry the front panel with you, put it in the supplied front panel case.
- Do not press hard or give excessive pressure to the display window of the front panel when attaching it to the unit.

ISO CONNECTOR

RCA Jack Line Out (Rear) -Gray

: Red (right)


: White (left)

CONNECTOR A

- 1.
- 2.
- 3.
4. MEMORY +12V
5. AUTO ANTENNA OUTPUT
- 6.
7. +12V (TO IGNITION KEY)
8. GROUND

Note:

(connector A no. 7) must be connected by car ignition key in order to avoid that car battery becomes weak when the car will be not used for long period.



CONNECTOR B

- 1. REAR RIGHT SPEAKER (+)
- 2. REAR RIGHT SPEAKER (-)
- 3. FRONT RIGHT SPEAKER (+)
- 4. FRONT RIGHT SPEAKER (-)
- 5. FRONT LEFT SPEAKER (+)
- 6. FRONT LEFT SPEAKER (-)
- 7. REAR LEFT SPEAKER (+)
- 8. REAR LEFT SPEAKER (-)

Maintenance

FUSE REPLACEMENT

If the fuse blows, check the power connecton and replace the fuse. If the fuse blows again after the replacement, there may be an internal malfunction. In this case, consult your nearest re-paring center.

Warning

Use the specified amperage fuse for each lead. Use of a higher amperage fuse may cause serious damage.

OPERATING INSTRUCTIONS

1. POWER ON/OFF

By pressing this key, the unit is switched on and off.
This unit is turned on by pressing any key.

2. SELECT

3. VOLUME UP/DOWN

Rotating these knob, you can adjust VOL/BASS/TREB/BAL/FAD. To select other functions, press the SEL (2) button shortly until the desired functions is shown on the display. Figure 1 shows how control functions are selected using the SEL button.




Fig. 1 Selection of sound control functions


- 1. VOL
- 2. SEL
- 3. BAS
- 4. TRE
- 5. BAL
- 6. FAD

VOL. UP Button (+) and VOL. DOWN Button (-). Increase or decrease the volme by or . These buttons can be used to adjust the BASS, TREBLE, BALANCE and FADER.

TA SEEK/TA ALARM (2)

When press the SEL button for more than 2 seconds, it is activated as selecting mode of these function.

TA SEEK Mode or TA ALARM mode is selected by or .



- TA SEEK mode:

When newly turned station does not receive TP information for 5 sec., the radio retunes to next station which has not the same station (PI) as the last station, but has the TP information.

In TA seek mode, the current station can be changed to the completely different station because the unit searches TP station when the field strength of the current station is very weak, or the current station has no TP signal.

- TA ALARM mode:

Any automatic retune mode is not activated, just can be heard Beep sound.

MASK DPI (2)

When press the SEL button for more than 2 seconds, it is activated as selecting mode of these function.



MASK DPI: masked only the AF which has different PI.

MASK ALL: masked the AF which has different PI and NO RDS signal with field strength.

RETUNE L / S CONTROLS (2)


When press the SEL button for more than 2 seconds, it is activated as selecting Retune mode.

RETUNE L: Select 90 seconds as the initial time of automatic TA search.

RETUNE S: Select 30 seconds as initial time.



**AUDIO DSP CONTROLS (2)**

When press the SEL button for more than 2 seconds, it is activated as selecting mode of these function.

**LOUDNESS CONTROLS (2)**


When press the SEL button for more than 2 seconds, it is activated as selecting mode of these function.



LOUD ON/OFF mode is selected by  or  key. The bass and treble response will be boosted.

ESP MODE (2)


When press the SEL button for more than 2 seconds, it is activated as 12 sec. or 45 sec. for CD of ESP mode can be selected.



Note: 12 sec./45 sec. for CD, 120 sec. for MP3.

MULTI CD SECTION MODE (2)


When press the SEL button for more than 2 seconds, it is activated as selecting mode of these function.



CD MULTI ON/OFF mode is selected by "VOL knob". CD MULTI ON: Read multi section CD. CD MULTI OFF: Read first section only.

BEEP MODE (2)


When press the SEL button for more than 2 seconds, it is activated as selecting mode of these function.



BEEP ON: BEEP sound can be heard from speaker when the buttons are pressed.

SEEK MODE (2)

When press the SEL button for more than 2 seconds, it is activated as selecting mode of these function.




SEEK 1: When SEEK 1 mode is activated, AUTO SEEK SCAN is stopped when station is detected even user still push SEEK button.

SEEK 2: Auto SEEK SCAN is not stopped even station is detected if user push SEEK button. When release this SEEK button, then stop when station is detected.

STEREO/MONO (2)


When press the SEL button for more than 2 seconds, it is activated as selecting mode of these function.



When FM stations are weak and are disturbed, listening can be improved by selecting MONO.

LOCAL/DX (2)

When press the SEL button for more than 2 seconds, it is activated as selecting mode of these function.



"Local" position in areas with strong signals to let radio stop at only strong stations during manual tuning (LOC appears). Press to Distant position in areas with weak signals to listen to all stations.

4. PRESET STATIONS (1,2,3,4,5,6)**(A) RADIO MODE:**

When pressed short, these keys select a preset station directly. When pressed longer than 1 sec., current station is stored in preset memory bank. When PTY mode is selected, the PTY switch is shared as follows:

PTY music group ---- PTY speech group ---- OFF

MUSIC

1. POP M, ROCK M
2. EASY M, LIGHT M
3. CLASSICS, OTHER M
4. JAZZ, COUNTRY
5. NATION M, OLDIES
6. FOLK M

SPEECH

1. NEWS, AFFAIRS, INFO
2. SPORT, EDUCATE, DRAMA
3. CULTURE, SCIENCE, VARIED
4. WEATHER, FINANCE, CHILDREN
5. SOCIAL, RELIGION, PHONE IN
6. TRAVEL, LEISURE, DOCUMENT

(B) CD/MP3 PLAYER MODE:

1. PAUSE
2. INT
3. RPT
4. RDM

USING THE RDS FUNCTION**What is RDS?**

The RDS (Radio Data System) is a digital information system developed by the EBU (European Broadcast Union). Piggy-backed on normal FM broadcasts, RDS offers a variety of information services and automatic retuning functions for RDS-compatible car stereos.

In 1988, RDS became available in the United Kingdom, France, West Germany, Ireland and Sweden. Test transmissions are being conducted in many other european countries. It is expected that RDS will be available in most western european countries in the near future.

5. 'AF/REG' function (ALTERNATIVE FREQUENCIES)

When pressed short, AF/REG switchig mode is selected.

When AF/REG switching mode is selected, the radio checks the signal strength of the AF all the time. When pressed long, it is activated as regional mode ON/OFF.

– Regional mode ON:

AF switching or PI SEEK is implemented to the station which have all PI codes same as current station. REG segment is turned on, in LCD display.

– Regional mode OFF

The regional code in the format of PI code is ignored when AF switching or PI SEEK is implemented.

6. 'TA' function (TRAFFIC ANNOUNCEMENT)

When pressed short, it is activated as TA mode on or off

When TA mode is on and traffic announcement is transmitted

- When the unit is in CD/MP3 mode, it will switch to radiomode temporarily.
- If the volume level was under the threshold point, it will be raised to the threshold point.
- When TP station is received, TP segment is turned on in LCD display.

7. 'PTY' function (PROGRAM TYPE)

PTY MUSIC ---- PTY SPEECH ---- PTY OFF

While selecting PTY type, its selection is implemented by preset buttons as described in preset key. When PTY is selected, the radio starts to search corresponding PTY information, and stops if the corresponding PTY information, is detected.

8. DISPLAY (DISP)

When this key is pressed, it is operated as the conversion of each display mode as follow.

1) In case of receiving RDS station.**RADIO MODE**

PS ---- CT ---- FREQ ---- PTY

CD/MP3 PLAYER MODE

CDP ---- CT ---- PS ---- FREQ ---- PTY

2) In case of receiving NON RDS station**RADIO MODE**

FREQ ---- CLOCK ---- NO PTY

CD/MP3 PLAYER MODE

CDP ---- FREQ ---- CLOCK ---- NO PTY

Each display time is several seconds, and come back to 1'st position after several seconds.

Notes: • **CT** = clock time

- **FREQ** = frequency

9. MODE BUTTON (MODE)

By pressing this key, user can select.

AUX/TUNER/CD-MP3/USB or MMC/SD mode.

10. BAND BUTTON (BAND)

Each band is toggled cyclically by pressing this key FM1---FM2---FM3.

11. AUTOMATIC OR MANUAL TUNING (FREQ UP ►► OR FREQ DOWN ◀◀)**(A) RADIO MODE**

When pressed short, these keys are operated as MANUAL tuning mode.

When pressed longer than 1 sec., they are operated as SEEK tuning mode.

(B) CD/MP3 PLAYER MODE

When pressed short, they are operated as TRACK UP or TRACK DOWN mode.

When pressed longer than 1 sec., they are operated as CUE or REVIEW mode.

12. AUTO SEEK SEARCH TUNING (A/PS)

By pressing shortly, the radio searches for each preset station.

When field strength level is bigger than the threshold level of stop level, the radio is holding at that preset number for 5 sec. with releasing mute, and then searches again.

By pressing longer than 1 sec, and then 6 strongest stations are preset to the corresponding preset number.

When AS operation is finished, the radio executes the preset scan.

13. 'SCAN' AUTOMATIC TUNING CONTROL (SCN)

This key is operated as RADIO SCAN

The operation is similar as normal search but different thing is holding 5 seconds on every station detected in RADIO SCAN mode.

14. LCD DISPLAY

The Liquid Crystal Display will display the current state of the unit.

CD CONTROL LOCATION OF PARTS**11. TRACK/SEARCH BUTTON****FORWARD AND REVERSE TRACK SEARCH (or changing songs)**

Press the SKIP button (**⏮** or **⏭**) during play to go to the desired track(song).

⏮REVERSE **⏭**FORWARD

Press and hold the SKIP button (**⏮** or **⏭**) during play to scan the disc at high speed. When the desired music section of the disc is found, release the button. Normal play will resume.

When CD/MP3 play is finished, CD/MP3 mode automatically changes to radio mode.

16. CD SLOT**17. CD EJECT BUTTON**

Press the EJECT button to remove the CD.

18. PAUSE BUTTON

During "PLAY", press (18) 'PAU' button to "PAUSE". Press it again to resume play.

19. INTRO BUTTON (Preview all Tracks)

When this button is pressed, 'INT ON' indication is displayed and the first several seconds of each track of the disc are played. Press again to stop intro and listen to track.

20. REPEAT BUTTON 'RPT'

When this button is pressed, 'RPT ON' indication is displayed and play of the selected track will be continually repeated until the Track repeat mode is cancelled by pressing 'RPT' button again.

21. RANDOM BUTTON 'RDM'





When this button is pressed, 'RDM ON' indication is displayed and each track of the disc are played in random instead of normal progression. To cancel RANDOM mode, press 'RDM' button (21) again.

22, 23. 10 TRACK UP/DOWN SELECT: (In case of MP3 files)





M5: 10 Track down / M6: 10 Track up

HOW TO SELECT MP3 FILES





1. Searching Track:

- Press “A/PS”, then searching track is activated.
- Press “SEL”, then the first digit is blinking.
- With “VOL  / VOL  ” knob, select first digit you want.
- Press “SEL”, then the first digit is fixed and second digit is blinking.
- With “VOL  / VOL  ” knob, select 2’nd 3’rd respectively.
- Then automatically the song you selected will start.

2. Searching File Name:

- Press “A/PS” twice, then file search is activated.
- Press “SEL”, then the first directory is displayed.
- With “VOL  / VOL  ” knob, you can select the directory you want.
- Press “SEL” again, then the directory is fixed and the first file name is displayed.
- With “VOL  / VOL  ” knob, you can select the file you want.
- Press “SEL”, then the song you selected will start.

3. Searching Character:

- Press “A/PS” 3 times, then character search mode is activated.
- Press enter “SEL” button, then “A” character is displayed.
- With “VOL  / VOL  ” knob, you can select the letter you want.
- Press enter “SEL” key longer than 2 sec.
- The song which has same character you selected is displayed.
- With “VOL  / VOL  ” knob, you can select the song you want.
- Press enter “SEL” key, then the song you selected will start.

• RESET

Reset button (24) is placed on the housing.

The reset button is to be activated for the following reason:

- Initial installation of the unit when all wiring is completed.
- All the function button do not operated.
- Error symbol on the display.

Connecting it to Portable MP3 Player

25. USB Port

Using USB cable to connect Your Portable MP3 Player.

*** IMPORTANT INFORMATION:**

This car radio has been designed following the latest USB technology.

The variety of memory stick available in the market, however, doesn't allow to make a product surely and fully compatible with all USB products of today and tomorrow.

26. MULTI-MEDIA CARD (MMC) / SD CARD SLOT

Support MP3 ID3 format music only.

SPECIFICATIONS

CD/MP3 PLAYER SECTION

| | |
|-----------------------|----------------|
| Signal to Noise Ratio | > 60dB |
| Channel Separation | > 50 dB (1kHz) |
| Frequency Response | 20Hz - 20 kHz |

TUNER

| | |
|------------------------|--------------|
| Sensitivity | 3 μ V |
| Stereo separation | 35 dB |
| Signal to noise ratio | 55 dB |
| Frequency range | 87.5-108 MHz |
| Channel step | 50 kHz |
| Intermediate frequency | 10.7 MHz |

LINE-OUT

| | |
|-----------|--------|
| Output | 350mV |
| Impedance | 10kOhm |

GENERAL

| | |
|-------------------|---------------------------------|
| Power Supply | 13.8V DC (10.8-15.6V allowable) |
| Speaker impedance | 4 or 8 ohm |
| Output power | 40W x 4CH |

Note: Specifications and the design are subject to possible modification without notice due to improvement.